



PIEZOELECTRIC SENSOR EVALUATION
FOR
STRUCTURAL HEALTH MONITORING
OF
CYROGENIC STRUCTURES

Robert Engberg

John Lassiter

Marshall Space Flight Center
Test Laboratory



OUTLINE



- Definitions in Structural Health Monitoring (SHM)
- Examples of various methods/sensors for SHM
- Our work at Marshall
 - Purpose for our research: Cryogenic structures
 - Type of sensors: Piezoelectric
 - Test methodology: Impedance
 - Examples of our tests and test results



What is SHM?

- A means to detect damage in any infrastructure (aerospace, civil, etc.)
- What is damage? Changes to material and geometric properties of a structure that can affect present and future performance
 - Also includes boundary conditions and connectivity
- Examples: fatigue crack, loosening of a bolted joint
- While subjected to operational loads, damage propagates
 - Causes component level failure
 - Continuous loading causes more component failures, leading to system failures



SHIM Process

- Involves observation of a system over time using periodically sampled measurements using an array of sensors
- Determine features of measurements that indicate the presence of damage
- Use statistical analyses to determine state of system health



So why conduct SHM?

- Long term is needed to verify a structure's ability (integrity) to perform as designed without failure:
 - Over any given length of time
 - Subjected to any given state of operational environment which is the actual cyclic loads placed on the structure
 - Example: Determine an aircraft's usage and remaining fatigue life

- Verify the integrity after some extreme event (i.e. earthquake, blast loading, impact, etc.)

- Goal is to provide an economic and life-safety advantage
 - From time based (called hard time replacement in RCM) to condition based maintenance
 - Accurate assessment of readiness for usage and operation



Sensors used in SHM

- Traditional sensors used in the experimental validation of the design of a structure are not considered in SHM
 - Foil type strain gages and displacement sensors are typically used to for static loads and fatigue tests
 - Accelerometers are typically used in dynamic (modal) tests
- Too many of these types of sensors are needed to detect small levels of wide spread changes in the strength and stiffness of a structure
- Other sensor technologies being researched
 - Fiber optic
 - Lamb wave propagation using piezoelectric devices
 - Impedance method using piezoelectric devices



What is piezoelectricity?

- Certain crystalline minerals called piezoceramics, when subjected to a mechanical force, become polarized
 - Tension and compression generate voltages of opposite polarity and proportional to the level of force
 - Comes from the Greek word piezein: to press or squeeze
- The converse is true: crystals exposed to an electric field lengthen or shorten in proportion to the field strength and polarity
- Piezoceramic: Mass of perovskite crystals having a tetravalent metal ion (titanium or zirconium) in a lattice of metal ions, usually lead or barium
 - Most widely used is PZT: lead zirconate titanate



Impedance based SHM

- Piezoceramic (PZT) patches couple the electrical impedance of the patch and the mechanical impedance of the structure
 - Mechanical impedance depends on mass, stiffness, and damping
- Any change in a structure's mass, stiffness, and damping due to damage will change its structural impedance, this in turn changes the electrical impedance of the patch since they are coupled
- Impedance measurements are complex (real and imaginary components) and are dependent on frequency
 - Typically high frequencies, > 30 kHz and low voltage (1 volt) to drive the patch



Tests at Marshall

- Work at Marshall centered on application of the impedance method of SHM for cryogenic structures
 - Cryogenic: Super cold!!!!!! Temperatures 100's of degrees below zero.
 - Cryogenic structures: primarily fuel tanks holding liquid oxygen (LOX) and liquid hydrogen

- Tests conducted to determine how the performance of the PZT patches are affected by cryogenic temperatures
 - Identify and remove the effects of these temperatures (and pressures)
 - Only changes in the impedance is due to damage in a structure





Tests at Marshall



- Two types of piezoceramic patches used:
 - PZT
 - Single crystal piezo (PMN-PT)

- First tests conducted Sep. '03
 - Patches attached to small composite plates
 - Placed in a small thermo chamber
 - 70 F to around -400 F, in 50 F increments






Tests at Marshall



- Measured impedance for various bandwidths (i.e., 5-10 kHz) for each temperature
- Observed changes in impedance with temperature
- Identify a statistical approach to characterize changes
- Answer questions such as: Does temperature have the same affects for each bandwidth






Tests at Marshall



- Second tests conducted Oct '03
 - Piezoceramic patches attached to composite over-wrapped pressure vessels (COPV)
 - Filled with water, ambient and various pressures
 - Measured impedance at various bandwidths for each pressure
 - Also conducted modal tests for each test configuration
 - Future plans include LN2





Tests at Marshall

- Third set of tests in progress
 - Similar to second set of tests
 - New plans will include impedance measurements of PZT patches in the free-free condition, not attached to any substrate
 - Determine the changes in impedance to the presence of a substrate
 - Imaginary as well as real component of impedance will be studied, previous tests only used the real component
- Results of tests may be used for future NASA SHM requirements
 - Man-rate an expendable launch vehicle for the CEV
 - Conduct SHM on extraterrestrial habitats for Moon and Mars exploration



Reference and web sites

- Most of the material in this presentation came from the SHM short course taught by Los Alamos Dynamics Structural Dynamics Consultants

- www.la-dynamics.com

- Web sites of piezoceramic manufacturers

- American Piezo Ceramics, Inc.; www.americanpiezo.com

- TRS Ceramics, Inc.; www.trsceramics.com

- Piezo Systems, Inc.; www.piezo.com